### Upgrading the Firmware on your Belkin VoIP Router

Step 1 Open Internet Explorer and type in the Address Bar <u>http://10.1.1.1</u>

(You will be presented with the following screen)



Step 2 In the password field type in admin and click LOGIN

#### Step 3 Click Advanced Setup

(You will be presented with the following screen)





F1PI242EGau



F1PI242ENau

### Step 4 Click Tools then Firmware Upgrade

(You will be presented with the following screen)



#### Step 5 Click Browse, find the file in c:\Belkin\F1PI242EGau

(You will be presented with the following screen)

	📋 My Docum	ents	• (	3 Ø B	• 🛄 •	
My Recent Desktop	Downloads GrabIt Down My Music My Pictures My Received My Videos					
61					12 13	

- Step 6 Click Open
- Step 7 Click Upgrade Firmware, then OK

(You will be presented with the following screen)



### You will now need to restore the unit to Factory Defaults

Step 1 Open Internet Explorer and type in the Address Bar <a href="http://10.1.1.1">http://10.1.1.1</a>



- Step 2 In the password field type in admin and click LOGIN
- Step 3 Click Advanced Setup
- Step 4 Click Tools then Configuration Tools

(You will be presented with the following screen)



- Step 5 Place the Dot next to Restore Router to Factory Defaults and click Next
- Step 6 Click APPLY

(You will be presented with the following screen)



### You will now need to re-enter your Username and Password Settings

Please do not use a saved configuration as it will not function correctly with the updated firmware.

Step 1 Open Internet Explorer and type in the Address Bar http://10.1.1.1

(You will be presented with the following screen)

le Edit Yew Pgyorites Icols Help	4
3 Back + 🕥 · 🖹 🗟 🏠 🔎 Search 👷 Favorites 🚱 🍰 - چ 🗔	
(dress 🛃 http://10.1.1.1/	💌 🛃 Go 🛛 Link
support - 132298 connect beffer	Copyright () 2005 liNet . All rights reserved.
Login Screen Password: Concerned password for Administrator Access, T Pesse enter correct password for Administrator Access, T We suggest that you use Internet Lipporer LS or above at a minimum Copyright © 2007 illet. All rights reserved.	

- Step 2 In the password field type in admin and click LOGIN
- Step 3 Under ADSL Parameter Setting Enter your Username and Password into the fields

(You will be presented with the following screen)



Step 4 Click Save Settings